





Instruction Manual

ThinkTop® DeviceNet™ 11-25 VDC



TD800100_3



The Top is identified by 4 fastening screws

The information herein is correct at the time of issue but may be subject to change without prior notice

| | |
|---|-----------|
| 1. EC Declaration of Conformity | 4 |
| 2. Safety | 5 |
| 2.1. Important information | 5 |
| 2.2. Warning signs | 5 |
| 2.3. Safety precautions | 6 |
| 3. General information | 7 |
| 3.1. DeviceNet™ in general | 7 |
| 4. Technical specifications | 9 |
| 4.1. ThinkTop ® DeviceNet™ features | 9 |
| 5. Installation | 18 |
| 5.1. Installation on air actuators | 18 |
| 5.2. Installation on Series 700 valves | 21 |
| 5.3. Air connections | 22 |
| 5.4. Electrical connection, internal | 23 |
| 6. Setup diagram | 24 |
| 6.1. ThinkTop setup utilising IR keypad | 24 |
| 6.2. ThinkTop setup utilising local 'I' and 'II' keys | 26 |
| 6.3. ThinkTop quick setup guide | 28 |
| 7. Fault finding | 30 |
| 7.1. Fault finding and LEDs | 30 |
| 8. Maintenance | 32 |
| 8.1. Dismantling of ThinkTop | 32 |
| 8.2. Assembly of ThinkTop | 34 |
| 8.3. Dismantling and assembly of Series 700 valves | 36 |
| 9. Part list and Service Kits | 37 |
| 9.1. Drawings for ThinkTop DeviceNet 11-25 VDC | 37 |
| 9.2. ThinkTop DeviceNet 11-25 VDC | 38 |
| 9.3. Drawings for ThinkTop Series 700 Valves | 40 |
| 9.4. ThinkTop Series 700 Valves | 41 |

1 EC Declaration of Conformity

The designating company

Alfa Laval
Company Name

Albuen 31, DK-6000 Kolding, Denmark
Address

+45 79 32 22 00
Phone No.

hereby declare that

| | | |
|--|----------------------------|-------|
| <u>Top Unit for Valve Control & Indication</u> | <u>ThinkTop®DeviceNet™</u> | _____ |
| Denomination | Type | Year |

is in conformity with the following directives with amendments:

- Low Voltage Directive (LVD) 2006/95/EF
- EMC Directive 2004/108/EF
- ROHS Directive 2002/95/EEC

Manager, Product Centres,
Compact Heat Exchangers & Fluid Handling

Title

Bjarne Søndergaard

Name

Alfa Laval Kolding

Company



Signature

Designation



*Unsafe practices and other important information are emphasized in this manual.
Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.
Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.*

2.1 Important information

Always read the manual before using the top unit!

WARNING

Indicates that special procedures must be followed to avoid serious personal injury.

CAUTION

Indicates that special procedures must be followed to avoid damage to the ThinkTop.

NOTE

Indicates important information to simplify or clarify procedures.

2.2 Warning signs

General warning:



Dangerous electrical voltage:



Caustic agents:



2 Safety

*Unsafe practices and other important information are emphasized in this manual.
Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.
Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.*

2.3 Safety precautions

Installation

Always read the technical data thoroughly.



Never install the ThinkTop before valve or relay is in a safe position.



If welding close to the ThinkTop: **Always** earth close to the welding area.



Disconnect the ThinkTop.



Always have the ThinkTop electrically connected by authorized personnel.



Maintenance

Always read the technical data thoroughly.



Always fit the seals between valve and ThinkTop correctly.



Never service the ThinkTop before valve or relay is in a safe position.



Never service the ThinkTop with valve/actuator under pressure.



Never clean the ThinkTop with high pressure cleaning equipment.



Never use cleaning agents when cleaning the ThinkTop. Check with cleaning agent supplier.



Unsafe practices and other important information are emphasized in this manual. Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page. Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

3.1 DeviceNet™ in general

DeviceNet™ is a low-cost communication link to connect industrial devices (such as limit switches, photoelectrical sensors, valve manifolds, motor starters, process sensors, bar cod readers, variable frequency drives, panel display and operator interfaces) to a network and eliminate expensive handwiring. The direct connectivity provides improved communication between devices as well as important device-level diagnostics not easily accessible or available through hardwired I/O interfaces. DeviceNet™ is a simple networking solution that reduces costs as well as time to wire and install industrial automation devices, while providing interchangeability of similar components from multiple vendors.

DeviceNet™ is an open network standard.

DeviceNet™ features and functionality

| | | |
|---------------------|---|-----------------|
| Network size | Up to 63 nodes | |
| Network length | Selectable end-to-end network distance varies with speed | |
| | Baud Rate | Distance |
| | 125 Kbps | 500 (1,640 ft) |
| | 250 Kbps | 250 (820 ft) |
| | 500 Kbps | 100 (328 ft) |
| Data Packets | 0-8 bytes | |
| Bus Topology | Linear (trunk line/drop line); power and signal on the same network cable | |
| Bus Addressing | Peer-to-Peer with Multi-Cast (one-to-many); Multi-Master and Master/Slave special case; polled or change-of-state (exception-based) | |
| System Features | Removal and replacement of devices from the network under power | |

The basic trunk line/drop line topology provides separate twisted pair busses for both signal and power distribution. Thick or thin cable can be used for either trunk lines or drop lines. End-to-end network distance varies with data rate and cable size.

| Data Rates | 125 Kbps | 250 Kbps | 500 Kbps |
|------------------------|------------------|----------------|----------------|
| Thick Trunk Length | 500 m (1,640 ft) | 250 m (820 ft) | 100 m (328 ft) |
| Thin Trunk Length | 100 m (328 ft) | 100 m (328 ft) | 100 m (328 ft) |
| Maximum Drop Length | 6 m (20 ft) | 6 m (20 ft) | 6 m (20 ft) |
| Cumulative Drop Length | 156 m (512 ft) | 78 m (256 ft) | 39 m (128 ft) |

The end-to-end network distance varies with data rate and cable thickness.

DeviceNet™ requires a terminating resistor to be installed at each end of the trunk:

- 121 Ohm
- 1% metal film
- 1/4 Watt

Terminating resistors should not be installed at the end of a drop line, only at the two ends of the trunk line.

For further information please see the DeviceNet™ Standard.

3 General information

*Unsafe practices and other important information are emphasized in this manual.
Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.
Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.*

DeviceNet™ Features

| | | | |
|---------------------------------|------------------|---------------------|---|
| Device Type | Generic | Master/scanner | N |
| Explicit peer to peer messaging | N | I/O Slave messaging | |
| I/O peer to peer messaging | N | • Bit strobe | N |
| Configuration consistency value | N | • Polling | Y |
| Faulted node recovery | N | • Cyclic | N |
| Baud rates | 125K, 250K, 500K | 125K, 250K, 500K | Y |
| Configuration method | EDS | | |

The end-to-end network distance varies with data rate and cable thickness.

Special DeviceNet™ functions Class 100 Attributes

- Setup commands
- Configurator
- Alarm setup
- Time Total
- Time Closed
- Time Open
- Time to maintenance
- Last stroke travel time
- Last stroke travel length (mm)
- Current position [mm] (0 - 80 mm)
- Activation's solenoid no. 1
- Activation's solenoid no. 2
- Activation's solenoid no. 3
- Open count
- Closed count
- Time of last maintenance

See also section 3.1.4 ThinkTop DeviceNet™ Attribute List

DeviceNet™ interface

Baud rates: 125k, 250K and 500k.
Polling and change of state (COS) I/O slave messaging.

Poll: 7 or 2 bytes (optional).

2 bytes = Input/outputs and alarms (class 4).
7 bytes = Input/outputs alarms and class 100/attributes.
7 bytes is standard.

Changing from 7 bytes to 2 bytes: remove jumper (#12 and #13). A power recycle is necessary when changing byte sizes.

COS: 2 bytes, 7 bytes is not supported.

Node address

Range: 0 – 63.
Default slave address: 63.


Power Supply

The power supply to the complete unit is taken from the DeviceNet.
Supply voltage: 11 – 25 V DC, as specified for the DeviceNet.
Supply current: Max. 45 mA (for sensor unit alone)
(excluding current to the solenoids and the external proximity switches).
Electrical connection: Direct cable gland entry (hard wired).
PG11 (ø4 - ø10 mm).
PG7 (ø3 - ø6.5 mm) option, external sensor.

Unsafe practices and other important information are emphasized in this manual.
Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.
Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

4.1 ThinkTop® DeviceNet™ features

“No Touch” sensor system



Type: Alfa Laval “No Touch” System. For wire connections: See 5.4 Electrical connection, internal”.

Features

- Tolerance programmes.
- Self adjustment programme (SRC/ARC valves only).
- Built-in maintenance monitor.
- Setup by internal push buttons or remote control (IR Keypad).
- Setup and local fault supervision.
- Setup saved at power shutdown.
- Visual LED Indicator lights.

Sensor System

Unique “No Touch” sensor system without any mechanical sensor adjustments. A magnet (indication pin) is mounted on the valve stem and the magnetic field (axial) is detected by sensor chips inside the sensor board. The measuring angle from each chip is used to locate the current position of the valve stem with an accuracy of $\pm 0.1\text{mm}$. Note that the distance to the indication pin can be $5\text{ mm} \pm 3\text{ mm}$.

Feedback signals

Input signals (produced by the sensor unit) transmitted over the DeviceNet™ - class 4.

Five feedback signals: Closed valve, open valve, seatlift 1, seatlift 2 and status.

The status signal is used for five purposes:

- To indicate that a setup is in progress (LED D).
- To indicate an error condition (LED D), (flashing = software error), (steady = hardware error).
- To indicate that maintenance is required (LED F).
- To indicate if there is a conflict in the self adjustment programme (LED F).
- To indicate if no communication exists between ThinkTop® and PLC (LED D, steady).

Tolerance programme

Individual programme according to valve types.

- Type 0: Bypass valve type / keep present valve type.
- Type 1: SRC/ARC and Series 700 valves, only when self adjustment is enabled - Not recommended.
- Type 2: LKB (LKLA-T).
- Type 3: Unique Mixproof, SMP-SC Spillage-Free, and SRC-PV.
- Type 4: SMP-SC, SMP-TO, SMP-BC, SMP-BCA, SBV, SRC, ARC, Unique SSV, Unique SSV Aseptic, Unique-TO and Series 700 valves.
- Type 5: All Parameters Set To Default (also valid for MH valve and SMP-EC (seat-lift indication not possible for SMP-EC)).

Preset and reset values: Tolerance programme No./Type 5 ($\pm 5\text{mm}$) and all functions are disabled.

Note! Important to select the right tolerance programme in order to ensure optimum controlled closeness of valves.

4 Technical specifications

Unsafe practices and other important information are emphasized in this manual. Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page. Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

Self Adjustment (SRC/ARC valves only)

The self adjustment feature is an exceptional aspect of the ThinkTop design. A programme can be activated to allow an adjustment of the tolerance band if the seals in the valve are being compressed or are worn. When the tolerance band of the unit has been adjusted 0.3 mm, an alert warning will appear in the form of a status signal and a flashing maintenance LED. After 0.5 mm adjustment an alarm warning appears: Loss of feedback signal, status signal and steady maintenance light indicating a replacement of the seal.

Built-in Maintenance Monitor

The unit can be preset to indicate when the time for maintenance of the valve has been reached. A status signal and flashing maintenance LED can be programmed to return after 3, 6, 9 or 12 months or more.

Technical specifications

Sensor system

Sensor accuracy: ± 0.1 mm.
 Distance to indication pin: 5 ± 3 mm.
 Stroke length: 0.1 - 80 mm.

Electrical connection:

Direct main cable gland entry (hard wired) PG11 (ø4 - ø10 mm).
 Direct external/sensor cable gland entry PG7 (ø3 - ø6.5 mm) option, external sensor.

Terminals

The terminal row of the sensor unit is equipped with screw terminals for both internal as well as external cables and wires. The terminals are suitable for wires up to 0.75 mm² (AWG 19).

External sensors

The external sensors are used for seat-lift supervision when seat-lift can not be internally detected. The sensors get their supply voltage from the terminal row. The output signals from the sensors are connected to two inputs on the terminal row on the internal sensor unit. If the actual setup is set for internal seat-lift, the corresponding external signal is not used, otherwise the external signal logically controls the corresponding feedback to the PLC (Programmable Logic Controller).


Note! If using external sensor, the sensor must be active/activated when performing a setup routine of the control head.

Supply voltage: As specified for the AS-Interface (typical 30VDC)
 Supply current: Max. 15 mA per sensor.
 Type of sensor: VDC, only 3-wire sensor, PNP.
 Cable length: Max. 3 m.

Alarm mask

Output signals received from the DeviceNet™ (consumed by the sensor unit).
 Four-bit mask to disable the alarm functions for the states “closed”, “open”, “seatlift 1” and “seatlift 2” respectively.

See also section 3.1.4 “ThinkTop® DeviceNet™ Attribute List”.



4 Technical specifications

*Unsafe practices and other important information are emphasized in this manual.
Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.
Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.*

Note: If the programmer wishes to detect a physical closed valve position in an “Open Valve” sensor position, then there is no longer any consistence between the sensor valve detection position and the visual indications of the ThinkTop.

Technical specifications solenoid valves

Solenoid signals

Output signals received from the DeviceNet™ (consumed by the sensor unit) - class 4.

Three bits to control the solenoid drives located in the sensor unit.

Internal connections (solenoids)

The solenoid drivers are reducing the solenoid power by PWM after activation. The number of solenoids actually mounted in the control head could be 0 - 3.

| Technical specifications | |
|---|---|
| Up to 3 solenoid valves in each unit. | |
| Type | 3/2 or 5/2 valve (only possible with one 5/2 valve). |
| Air supply | 300-900 kPa (3-9 bar). |
| Filtered air, max. particles or dirt | 5 µ 5-5 mg/m ³ . |
| Max. flow | 180 l/min. |
| Max. oil content | 1 mg/m ³ . |
| Max. water content | 0.88 g/m ³ -20 °C compressed air. |
| Throughput | ø2.5 mm. |
| Air restriction (throttle function) air inlet/outlet. | Yes. |
| Manual hold override. | Yes. |
| External air tube connection | ø6 mm or 1/4" (specify when ordering). |
| Silencer/filter | Connection possible via ø6 mm or 1/4". (Filter recommended in tropical regions). |
| Solenoids drive | |
| Solenoid valve | 8 VDC. |
| O/P Valtage | 8 VDC +/- 5% |
| Power consumption | 0.75W Max. |
| Current consumption (per solenoid) | 30mA Max. |
| PWM Pull-in pulse length | 150ms Max. |
| PWM duty cycle | 40% +/- 10% |
| PWM frequency | 2 kHz +/- 10% |
| PWM = Pulse width modulated | |
| *) Note! Filter recommended in tropical regions. | |

Technical specifications aux. outputs

Three aux. outputs can be used for external devices. The drivers are always NPN outputs and PWM mode is not possible. The number of aux. outputs for activation of external devices can be 0-3. Clarification: All 3 outputs can be activated at the same time but if solenoid 1 is in use, aux. 1 can not be used! If solenoid 1 and 2 are in use, aux. 1 and 2 can not be used! If solenoid 1, 2 and 3 are in use, no aux. can be used! A mix of solenoid and aux. outputs is possible.

Output: NPN (sinking).

Output voltage: 24 VDC ± 15%. Network power connection! User must ensure 24 VDC on the network (at the top) when these outputs are used.

Load current: Max 75 mA.

As these outputs drive constant current, using several nodes in this mode will reduce the number of nodes supported by a typical 8A network supply. The user must ensure that total network current consumption is less than the supply rating.

ThinkTop®, EDS file

Please see web address www.odva.org for further information and for downloading the EDS file or contact your Alfa Laval company.

4 Technical specifications

Unsafe practices and other important information are emphasized in this manual.

Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.

Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

ThinkTop DeviceNet™ attribute list

| Name | | | Path | | | R/W/CS | data type | Raw data | |
|---------------------|-------|------|------------|------|--------|--------|-----------|----------|------------|
| | Class | Inst | Attributes | | | | | len. | LSB |
| Release DNET 4.6 | | | dec. | hex. | "poll" | | | | |
| Valve value | 4 | 1 | 3 | - | - | R | Byte | 1 | - |
| Valve command | 4 | 3 | 3 | - | - | R/W | Byte | 1 | - |
| Alarm status | 4 | 4 | 3 | - | - | R | Byte | 2 | - |
| Alarm mask | 4 | 5 | 3 | - | - | R/W | Byte | 2 | - |
| Extended status #1 | 100 | 1 | 101 | 65 | 01 | R | Byte | 3 | - |
| Extended Status #2 | 100 | 1 | 102 | 66 | 02 | R | Byte | 3 | - |
| Setup command | 100 | 1 | 110 | 6E | 0A | R/W | Byte | 1 | - |
| Configuration | 100 | 1 | 111 | 6F | 0B | R | Byte | 2 | - |
| Alarm #1 Setup | 100 | 1 | 121 | 79 | 15 | R/W | Byte | 2 | 0.524 sec. |
| Alarm #2 Setup | 100 | 1 | 122 | 7A | 16 | R/W | Byte | 2 | 0.524 sec. |
| Alarm #3 Setup | 100 | 1 | 123 | 7B | 17 | R/W | Byte | 2 | 0.524 sec. |
| Alarm #4 Setup | 100 | 1 | 124 | 7C | 18 | R/W | Byte | 2 | 0.524 sec. |
| Alarm #5 Setup | 100 | 1 | 125 | 7D | 19 | R/W | Byte | 2 | 0.524 sec. |
| Alarm #6 Setup | 100 | 1 | 126 | 7E | 1A | R/W | Byte | 2 | 0.524 sec. |
| Current position | 100 | 1 | 130 | 82 | 1E | R | UINT | 2 | 0.01982 m |
| Time TOTAL | 100 | 1 | 131 | 83 | 1F | R | UINT | 2 | 2.38 hrs. |
| Time CLOSED | 100 | 1 | 132 | 84 | 20 | R | UINT | 2 | 2.38 hrs. |
| Time OPEN | 100 | 1 | 133 | 85 | 21 | R | UINT | 2 | 2.38 hrs. |
| Time to Maint. | 100 | 1 | 134 | 86 | 22 | R | UINT | 2 | 2.38 hrs. |
| Last stroke Time | 100 | 1 | 135 | 87 | 23 | R | UINT | 2 | 0.131 sec. |
| Last Stroke Length | 100 | 1 | 136 | 88 | 24 | R | UINT | 2 | 0.01982 mm |
| Coil Count #1 | 100 | 1 | 137 | 89 | 25 | R | ULINT | 4 | counts |
| Coil Count #2 | 100 | 1 | 138 | 8A | 26 | R | ULINT | 4 | counts |
| Coil Count #3 | 100 | 1 | 139 | 8B | 27 | R | ULINT | 4 | sounts |
| OPEN Count | 100 | 1 | 140 | 8C | 28 | R | ULINT | 4 | counts |
| CLOSED Count | 100 | 1 | 141 | 8D | 29 | R | ULINT | 4 | counts |
| Time of Last Maint. | 100 | 1 | 142 | 8E | 2A | R | UINT | 2 | 2.38 hrs. |

4 Technical specifications

Unsafe practices and other important information are emphasized in this manual.

Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.

Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

ThinkTop® DeviceNet™ attribute list

| Name | Eng. Units Conv. | | | Bit maps/data | | | |
|---------------------|------------------|---------|-------|-----------------|---------------|---------------|--------|
| | mult. | divisor | units | byte 1 | byte 2 | byte 3 | byte 4 |
| Release DNET 4.6 | - | - | - | PLC_image | - | - | - |
| Valve value | - | - | - | Solenoids 1,2&3 | - | - | - |
| Valve command | - | - | - | Alarm_Status | Travelstatus | - | - |
| Alarm status | - | - | - | Alarm_Mask | Travel Mask | - | - |
| Alarm mask | - | - | - | Error_Byte | PLC_Image | LED_Image | - |
| Extended status #1 | - | - | - | Alarm_Status | Travel_Status | Adjust_Status | - |
| Extended Status #2 | - | - | - | ASI_Data(4...7) | - | - | - |
| Setup command | - | - | - | M_Config | D-Config | - | - |
| Configuration | - | - | - | End condition | Time | - | - |
| Alarm #1 Setup | - | - | - | End condition | Time | - | - |
| Alarm #2 Setup | - | - | - | End condition | Time | - | - |
| Alarm #3 Setup | - | - | - | End condition | Time | - | - |
| Alarm #4 Setup | - | - | - | End condition | Time | - | - |
| Alarm #5 Setup | - | - | - | End condition | Time | - | - |
| Alarm #6 Setup | - | - | - | End condition | Time | - | - |
| Current position | 991 | 50,000 | mm | LSB | MSB | - | - |
| Time TOTAL | 992 | 10,000 | days | LSB | MSB | - | - |
| Time CLOSED | 992 | 10,000 | days | LSB | MSB | - | - |
| Time OPEN | 992 | 10,000 | days | LSB | MSB | - | - |
| Time to Maint. | 992 | 10,000 | days | LSB | MSB | - | - |
| Last stroke Time | 131 | 10,000 | sec. | LSB | MSB | - | - |
| Last Stroke Length | 991 | 50,000 | mm | LSB | MSB | - | - |
| Coil Count #1 | - | - | - | LSB | mid byte | MSB | 0 |
| Coil Count #2 | - | - | - | LSB | mid byte | MSB | 0 |
| Coil Count #3 | - | - | - | LSB | mid byte | MSB | 0 |
| OPEN Count | - | - | - | LSB | mid byte | MSB | 0 |
| CLOSED Count | - | - | - | LSB | mid byte | MSB | 0 |
| Time of Last Maint. | 992 | 10,000 | days | LSB | MSB | - | - |

4 Technical specifications

*Unsafe practices and other important information are emphasized in this manual.
Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.
Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.*

ThinkTop® DeviceNet™ bit mappings

| | | | | | | | | |
|--|-----------------------|-------------------------|------------------------------|------------------------------|------------------------------|---------------------------|---------------------------|---------------------------|
| PLC_Image (feedbacks) | Travel in progress | Alarm timer expired | x | Maint. | SL2 | SL1 | OPEN | CLOSED |
| LED_Image | x | x | CLOSED | Maint. | Coil | Seat Lift | Setup | OPEN |
| Error_Byte | Multiple coil request | Timeout on last command | Button II failure | Button I failure | Tx/Rx failure | Bus Offline | Position Over Range | Check Sum Error |
| Solenoid 1,2 &3 | x | x | x | x | Coil #3 | Coil #2 | Coil #1 | x |
| Adjust_Status | x | x | CLOSED x | CLOSED x | OPEN Alarm | Alert | Alarm | x |
| Travel_Status | Travel in Progress | x | x | x | x | x | x | x |
| Timeout Alarm_Status | Timer Running | On last command | Alarm #6 active | Alarm #5 active | Alarm #4 active | Alarm #3 active | Alarm #2 active | Alarm #2 active |
| Alarm Setup (1..6) End condition: Time: LSB=0.524 sec. | Steady | x | x | x | SL2 | SL1 | OPEN | CLOSED |
| | ~ 67,1 s | ~ 33,5 s | ~ 16,8 s | ~ 8,4 s | ~ 4,2 s | ~ 2,1 s | ~ 1,0 s | ~ 0,5 s |
| Alarm Mask | x | x | Coil #3 de-energize enabled | Coil #2 de-energize enabled | Coil #1 de-energize enabled | Coil #3 energize enabled | Coil #2 energize enabled | Coil #1 energize enabled |
| Travel Mask | x | x | Coil #3 de-energize disabled | Coil #3 de-energize disabled | Coil #3 de-energize disabled | Coil #3 energize disabled | Coil #3 energize disabled | Coil #3 energize disabled |

4 Technical specifications

Unsafe practices and other important information are emphasized in this manual.

Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.

Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

ThinkTop DeviceNet Poll and COS command structures

Poll Request Message format

| byte | bit | | | | | | | |
|------|-----------------------------|---|--|--|--|--|--|--|
| | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 0 | x | x | x | x | Coil #3 de-energize | Coil #2 de-energize | Coil #1 de- energize | x |
| 1 | x | x | Alarm #6 enable coil #3 engrize | Alarm #5 enable coil #2 engrize | Alarm #4 enable coil #1 engrize | Alarm #3 enable coil #3 engrize | Alarm #2 enable coil #2 engrize | Alarm #1 enable coil #1 engrize |
| 2 | Write Attrib. Flag | Requested index for Class #100 attribute. Note: The index is 0-relative based on attribute ID #100 | | | | | | |
| 3 | Attribute Data Byte 0 - LSB | | | | | | | |
| 4 | Attribute Data Byte 1 | | | | | | | |
| 5 | Attribute Data Byte 2 | | | | | | | |
| 6 | Attribute Data Byte 3 - MSB | | | | | | | |

Poll Response Message Format

| byte | bit | | | | | | | |
|------|--------------------------------|---|--------------------|--------------------|--------------------|--------------------|--------------------|--------------------|
| | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 0 | Travel in Progress Timer | Timer Expired | x | MAINT. ERROR | Seat #2 Status | Seat #1 Status | OPEN Status | CLOSED Status |
| 1 | Running | Timer Expired | Alarm #6 active | Alarm #5 active | Alarm #4 active | Alarm #3 active | Alarm #2 active | Alarm #1 active |
| 2 | Valid Data Flag | Requested index for Class #100 attribute. Note: The index is 0-relative based on attribute ID #100 | | | | | | |
| 3 | Attribute Data Byte 0 - LSB | | | | | | | |
| 4 | Attribute Data Byte 1 | | | | | | | |
| 5 | Attribute Data Byte 2 | | | | | | | |
| 6 | Attribute Data Byte 3 - MSB | | | | | | | |

Note! The 2 bytes Poll command structure is the same as the 7 bytes command with only bytes 0,1 used.

4 Technical specifications

Unsafe practices and other important information are emphasized in this manual. Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page. Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

COS command structure

COS Request Message

By definition the COS and Poll Request Messages are identical. For a device configured for a 7 bytes Poll, the corresponding COS request will be:

| byte | bit | | | | | | | |
|------|---|---|-------------------------------------|-------------------------------------|-------------------------------------|----------------------------------|----------------------------------|----------------------------------|
| | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 0 | x | x | x | x | Coil #3 energize | Coil #2 energize | Coil #1 energize | x |
| 1 | x | x | Alarm #6 enable coil #3 de-energize | Alarm #5 enable coil #2 de-energize | Alarm #4 enable coil #1 de-energize | Alarm #3 enable coil #3 energize | Alarm #2 enable coil #2 energize | Alarm #1 enable coil #1 energize |
| 2 | Write Attrib. Flag Requested index for Class #100 attribute. Note: The index is 0-relative based on attribute ID #100 | | | | | | | |
| 3 | Attribute Data Byte 0 - LSB | | | | | | | |
| 4 | Attribute Data Byte 1 | | | | | | | |
| 5 | Attribute Data Byte 2 | | | | | | | |
| 6 | Attribute Data Byte 3 - MSB | | | | | | | |

For a device configured for a 2 bytes Poll, the corresponding COS request will be.

| byte | bit | | | | | | | |
|------|-----|---|-------------------------------------|--------------------------------------|-------------------------------------|----------------------------------|----------------------------------|----------------------------------|
| | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 0 | x | x | x | x | Coil #3 energize | Coil #2 energize | Coil #1 energize | x |
| 1 | x | x | Alarm #6 enable coil #3 de-energize | Alarm #65 enable coil #2 de-energize | Alarm #4 enable coil #1 de-energize | Alarm #3 enable coil #3 energize | Alarm #2 enable coil #2 energize | Alarm #1 enable coil #1 energize |

COS Response Message:

Only a 2 bytes message is supported and corresponds to the 2 bytes Poll response message format.

| byte | bit | | | | | | | |
|------|--------------------|---------------|-----------------|-----------------|-----------------|-----------------|-----------------|-----------------|
| | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 0 | Travel in Progress | Timer Expired | x | MAINT. ERROR | Seat #2 Status | Seat #1 Status | OPEN Status | CLOSED Status |
| 1 | Timer Running | Timer Expired | Alarm #6 active | Alarm #5 active | Alarm #4 active | Alarm #3 active | Alarm #2 active | Alarm #1 active |

Note! A 7 bytes COS response message is not supported.

COS Trigger

The COS message is triggered by any change in the Valve Value (feedbacks) corresponding to byte-0 of the COS response message.

4 Technical specifications

*Unsafe practices and other important information are emphasized in this manual.
Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.
Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.*

Typical power consumption

| | | | |
|------------------|---|-----------------------|--------|
| Test conditions: | One ThinkTop DeviceNet™ 11-25 VDC connected to the network with 1 input (on) and: | | |
| | No solenoids on | supply voltage 25 VDC | 20 mA |
| | 1 solenoid active (PWM) | supply voltage 25 VDC | 28 mA |
| | 2 solenoid active (PWM) | supply voltage 25 VDC | 36 mA |
| | 3 solenoid active (PWM) | supply voltage 25 VDC | 44 mA |
| | No solenoids on | supply voltage 11 VDC | 34 mA |
| | 1 solenoid active (PWM) | supply voltage 11 VDC | 58 mA |
| | 2 solenoid active (PWM) | supply voltage 11 VDC | 82 mA |
| | 3 solenoid active (PWM) | supply voltage 11 VDC | 106 mA |

Note: If the Aux. Outputs are used instead of the solenoids for activation of external devices, the consumption is depending on the load current (see "Aux. Outputs").

Materials

| | |
|---------------------|---|
| Plastic parts | Nylon PA12 |
| Steel parts | Stainless steel AISI 304 and 316 |
| Seals | FPM (air fittings), EPDM rubber for SMP-EC stem |
| Gore Vent. membrane | PBT plastic |

Micro environment demand specifications

| | | |
|-------------------------|---|----------------------------|
| Temperature | | |
| Working: | -20°C to +85°C | IEC 68-2-1/2 |
| Storage: | -40°C to +85°C | IEC 68-2-1/2 |
| Temperature change: | -25°C to +70°C | IEC 68-2-14 |
| Vibration | | |
| | 10-55 Hz, 0.7 mm | IEC 68-2-6 |
| | 55-500 Hz, 10g | |
| | 3 x 30 min, 1 octave/min | |
| Drop test | | |
| | | IEC 68-2-32 |
| Humidity | | |
| Constant humidity: | +40°C, 21 days, 93% R.H. | IEC 68-2-3 |
| Cyclic humidity: | +25°C/+55°C | |
| | 12 cycles | IEC 68-2-30 |
| (working) | 93% R.H. | |
| Protection class | | |
| | IP66 and IP67 | IEC 529 |
| Input threshold | | |
| Voltage/current: | Type 1 input requirements | EN 61131-2 |
| EMC Directive | | |
| | 2004/108/EF | EN 61000-6-3, EN 61000-6-2 |
| AS-Interface | | |
| | Version 2.1*) | EN50295 |
| | Version 3.0 **) | |
| UL Approval | | |
| | 8-30 VAC/VDC, Class 2 input, 45 mA max. output | UL 508-E203255 |

*) Max. 31 ThinkTop units on a single master/gateway. **) Max. 62 ThinkTop units on a single master/gateway.

5 Installation

Unsafe practices and other important information are emphasized in this manual. Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page. Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

5.1 Installation on air actuators

Step 1



Always read the technical data thoroughly.




Always have the ThinkTop electrically connected by authorized personnel.

Step 2


1. Fit the air fittings on actuator if not mounted.
2. Fit the activator stem (magnet) and tighten **carefully** with a spanner.

SRC/ARC only




Step 3

1. Place the ThinkTop on top of the actuator.
2. Make sure X-ring is mounted.



Step 4


1. Ensure that the unit is correctly mounted by **pressing** down on top of the ThinkTop.
2. Tighten the two Allen screws **carefully** (1.50 Nm).
3. Turn the actuator to have LEDs in a front view.



Unsafe practices and other important information are emphasized in this manual. Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page. Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.


Step 5

Fit the $\varnothing 6$ mm (1/4") air tubes to ThinkTop.
(see drawing "Air connections" page 22).




Step 6

Fit the air tubes to the actuator
(see drawing "Air connections" page 22).




Step 7

Untighten the four screws and pull off cover of ThinkTop.



Step 8

1. Install cable (if not present) through the cable gland.
2. Connect the ThinkTop electrically
(see page 5.4 Electrical connection, internal).




5 Installation

Unsafe practices and other important information are emphasized in this manual. Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page. Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

Step 9

Make sure the cable gland is completely tightened.



Step 10

Set up the ThinkTop (see chapter 6 Setup diagram).

NOTE!

The unit can be set up with the cover installed by using the IR keypad. To energize the valve, use a separate air tube or be in radio contact with the control room.


Unsafe practices and other important information are emphasized in this manual. Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page. Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

5.2 Installation on Series 700 valves

Step 1


1. Remove the cover by loosening the four cover screws.
2. Separate the adapter from the base by loosening the three recess screws on top of the base.

Installation on air actuators:




Step 2

1. Fit air fittings on actuator.
2. Position packing retainer in recess on actuator top.
3. Fit counter nut and indication pin (magnet) on actuator rod. Engage approx. 1/4" thread. Tighten counter nut and indicator with two wrenches.




Step 3

1. Place the two O-rings in the grooves in the bottom of the adapter. Then place the adapter on the actuator top. The small O-ring must be positioned over the air hole on the actuator.
2. Fasten the adapter with the four 5/16" Allen screws.



Step 4


Mount the base on the adapter in the position needed (can be rotated 120° in both directions). Note that one of the screw towers on the adapter has a guide recess (see * on drawing).



5 Installation

Unsafe practices and other important information are emphasized in this manual. Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page. Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

5.3 Air connections



- A. Air restriction (throttle function) air inlet/outlet
- B. Air out 1A
- C. Air exhaust
- D. Air out 1B (5/2 port solenoid valve only)
- E. Solenoid 3/2 or 5/2
- F. 3/2 Solenoid valves only
- G. Air restriction (throttle function) air inlet/outlet
- H. Air in
- I. Air out 3
- J. Air out 2
- K. Manual hold override

*Unsafe practices and other important information are emphasized in this manual.
Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.
Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.*

5.4 Electrical connection, internal




Table 1. Note!

- *) Terminals 24, 25, 26 and 27 can be used for external seat lift sensors as well as for any digital input. Always use an external PNP sensor. Two external signals can be connected, they are associated with feedback signal 3 (seat lift 1) and 4 (seat lift 2). External sensor must always be a 8-30 VDC PNP 3 wire sensor. Connect (-) common on terminal 27, and (+) common on terminal 26. The signals from the external sensors are associated as follows: sensor signal on terminal 24 (seat lift 1) associated with feedback 3 (seat lift 1), and sensor signal on terminal 25 (seat lift 2) associated with feedback 4 (seat lift 2).
- ***) Jumper present = PWM. See section 3.1.3 "Technical specifications solenoid valves".
- ****) Internal connections: Terminals for connection for the solenoids mounted internally in the control head. The number of solenoids actually mounted in the control head could be 0 - 3. The signals are taken directly from the terminal row.
- *****) If using external sensor, the sensor must be active/activated when performing a set-up routine of the control head.

6 Setup diagram

Unsafe practices and other important information are emphasized in this manual. Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page. Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

6.1 ThinkTop setup utilising IR keypad

General

Flashing LED means no value set. Steady LED means value set as shown

Default: Step 2, Factory set tolerance band +/- 5mm
Step 3-8, disabled

D LED: Active during set-up: Flashing in step 1
Steady in all other steps

Or during operations, error condition: Steady showing hardware fault, indication pin out of range
Flashing showing software fault

Timeout: A 60 sec. timeout is started as soon as any button(s) are released
On timeout the setup is exited with no changes saved

IR Keypad: Remote distance 0-300 mm to ThinkTop

Symbols

Push key on IR keypad with the same number

Simple representation of LED indication:

| | | | |
|-------------|---|-------------------------------------|--------------|
| Yellow | B | <input type="checkbox"/> | |
| IR-Receiver | | <input type="radio"/> | |
| Red | D | <input checked="" type="checkbox"/> | Steady LED |
| Yellow | C | <input type="checkbox"/> | |
| Green | E | <input type="checkbox"/> | |
| Orange | F | <input type="checkbox"/> | |
| Yellow | A | <input checked="" type="checkbox"/> | Flashing LED |




General commands in each step (except step 1):

| | | |
|----------------------------|-----------------------|---|
| <input type="checkbox"/> 0 | Next step / skip step | (In step 3-6 the program automatically moves to the next step when a position is stored) |
| <input type="checkbox"/> 5 | Clear / disable step | (In step 2 this resets the unit and set the step 2-8 to default) (The command is accepted when all unit LED's flash briefly) |

**It is recommended to reset the unit before performing a setup
Always check for correct signals after the setup**

6 Setup diagram

Unsafe practices and other important information are emphasized in this manual.
Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.
Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.



6 Setup diagram

Unsafe practices and other important information are emphasized in this manual. Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page. Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

6.2 ThinkTop setup utilising local 'I' and 'II' keys

General

Default is: Step 2, tolerance is +/- 5mm
Step 3-8, disabled

Timeout: A 60 sec. timeout is started as soon as any button(s) are released
On timeout the setup is exited with no changes saved

Flashing LED means no value set. Steady LED means value set as shown
[D] LED: Active during set-up: Flashing in step 1
Steady in all other steps

Or during operations, error condition: Steady showing hardware fault, indication pin out of range
Flashing showing software fault

General commands in each step (except step 1):

| | | |
|-----------------|-----------------------|---|
| ⓘ | Next step / skip step | (In step 3-6 the program automatically moves to the next step when a position is stored) |
| ⓘ _{5s} | Clear / disable step | (In step 2 this resets the unit to default) (The command is accepted when all unlit LED's flash briefly) |

It is recommended to reset the unit before performing a setup

Symbols

| | |
|-----------------|-------------------------|
| ⓘ | Push local key "I" |
| ⓘ | Push local key "II" |
| ⓘ _{5s} | Hold key "II" for 5 sec |


Simple representation of LED indication:

| | | | |
|-------------|---|-------------------------------------|--------------|
| Yellow | B | <input type="checkbox"/> | |
| IR-Receiver | | <input type="checkbox"/> | |
| Red | D | <input checked="" type="checkbox"/> | Steady LED |
| Yellow | C | <input type="checkbox"/> | |
| Green | E | <input type="checkbox"/> | |
| Orange | F | <input type="checkbox"/> | |
| Yellow | A | <input checked="" type="checkbox"/> | Flashing LED |



6 Setup diagram

Unsafe practices and other important information are emphasized in this manual. Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page. Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.



6 Setup diagram

*Unsafe practices and other important information are emphasized in this manual.
Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.
Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.*

6.3 ThinkTop quick setup guide

Valve: Unique SSV, SRC/ARC type NC (selfadjustment disabled)

| | | |
|-------|----------|--|
| Push: | | - and wait until red LED flashes |
| Push: | | |
| Push: | | - hold for 5 sec (clear all stored parameters) |
| Push: | | (red + yellow LED) |
| Push: | | (red + yellow + green LED) |
| Push: | | (red + yellow + green + orange LED) |
| Push: | | (red + yellow + green + orange + yellow LED) |
| Push: | | |
| Push: | | - to approve valve down (closed) |
| | Activate | Valve opens |
| Push: | | - to approve (open) |
| Push: | | (no upper seat-lift) |
| Push: | | (no lower seat-lift) |
| Push: | | (no self adjustment) |
| Push: | | (no maintenance) |
| Push: | | Red LED flashes (save & exit by push) |



Setup
done

Valve: SRC/ARC type NO (selfadjustment enabled)

| | | |
|-------|------------|--|
| Push: | | - and wait until red LED flashes |
| Push: | | |
| Push: | | - hold for 5 sec (clear all stored parameters) |
| Push: | | (red + yellow LED) |
| Push: | | |
| | Activate | Valve closes |
| Push: | | - to approve valve closed |
| Push: | Deactivate | Valve opens |
| Push: | | - to approve valve is open |
| Push: | | (no upper seat-lift) |
| Push: | | (no lower seat-lift) |
| Push: | | = self adjustment |
| Push: | | |
| Push: | | (no maintenance) |
| Push: | | Red LED flashes (save & exit by push) |



Setup
done

Valve: LKB Valve (Butterfly) NC

| | | |
|-------|----------|---|
| Push: | | - and wait until red LED flashes |
| Push: | | |
| Push: | | - hold for 5 sec |
| Push: | | (red + yellow LED) |
| Push: | | (red + yellow + green LED) |
| Push: | | |
| Push: | | - to approve valve closed (indication stem up) |
| Push: | Activate | LKB valve- open position (indication-stem down) |
| Push: | | - to approve valve is open |
| Push: | | (no upper seat-lift) |
| Push: | | (no lower seat-lift) |
| Push: | | (no self adjustment) |
| Push: | | (no maintenance) |
| Push: | | Red LED flashes (save & exit by push) |



Setup
done

6 Setup diagram

Unsafe practices and other important information are emphasized in this manual.

Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.

Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.

Valve: LKB Valve (Butterfly) NO

| | | |
|-------|------------|--|
| Push: | I | - and wait until red LED flashes |
| Push: | I | |
| Push: | II | - hold for 5 sec (clear all stored parameters) |
| Push: | II | (red + yellow LED) |
| Push: | II | (red + yellow + green LED) |
| Push: | I | |
| Push: | Activate | - to approve valve closed (indication stem up) |
| Push: | II | - to approve valve closed |
| Push: | Deactivate | LKB valve-open position (indication-stem up) |
| Push: | II | - to approve valve is open |
| Push: | I | (no upper seat-lift) |
| Push: | I | (no lower seat-lift) |
| Push: | I | (no self adjustment) |
| Push: | I | (no maintenance) |
| Push: | II | Red LED flashes (save & exit by push) |
| | Setup done | |



Valve: Unique mixproof Valve (with lower seat-lift)

| | | |
|-------|------------|--|
| Push: | I | - and wait until red LED flashes |
| Push: | I | |
| Push: | II | - hold for 5 sec (clear all stored parameters) |
| Push: | II | (red + yellow LED) |
| Push: | II | (red + yellow + green LED) |
| Push: | II | (red + yellow + green + orange LED) |
| Push: | I | |
| Push: | II | - to approve valve closed |
| Push: | Activate | Valve opens |
| Push: | II | - to approve valve is open |
| Push: | Activate | Lower seat-lift active |
| Push: | II | - to approve |
| Push: | I | (no self adjustment) |
| Push: | I | (no maintenance) |
| Push: | II | Red LED flashes (save & exit by push) |
| | Setup done | |






7 Fault finding

Unsafe practices and other important information are emphasized in this manual. Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page. Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.



7.1 Fault finding and LEDs

Below is stated the meaning of the LEDs' indications for fault finding in connection with the operation of the ThinkTop.

7.1.1 status LED (Red)

| | | |
|---|---------------|---|
|  | Red flashing: | Unit in set-up mode or internal software fault. If internal software fault, re-programme unit. |
|  | Red steady: | Unit in set-up mode or internal hardware fault. If internal hardware fault, check if magnet is in range and check correct wiring. |
|  | Red steady: | No. communication between ThinkTop and the DeviceNet master, i.e. the bus is offline. If the Red LED is with random intervals and duration, it suggests that the bus is unstable, and the DeviceNet network should then be investigated. There are numerous issues that could lead to marginal operation of a network, bus load, voltage limits, impedance, termination, etc. |

7.1.2 Maintenance time out

| | | |
|---|--|---|
|  | 1 Orange flashing: | Time for maintenance has run out. The unit has been self-adjusted into a maintenance alert condition. Valve maintenance is strongly recommended. After maintenance: Disabling of maintenance/self-adjustment function is required before setting new position, however, it is strongly recommended to make a complete new set-up after valve maintenance. |
|  | 2 Orange steady, yellow flashing (A and/or B): | The unit has been self-adjusted into a maintenance alarm condition and the feedback is lost (a minimum of seal left). Valve maintenance is required. After maintenance: Disabling of the self-adjustment function is required before setting new position, however, it is strongly recommended to make a complete new set-up after valve maintenance. |

NOTE!





The maintenance indicator lighting up, and an open or closed light flashing..... =

Note the following:

- Self-adjustment programme is only valid for SRC/ARC valves, do not use the programme for other valve types.
- Use tolerance/valve type 1.
- In conjunction with valve type change-over; 21, 22, 31 and 32, the open position must be defined as the upper sensor position (when the indication pin is in the highest position).
- A loose top, indication pin or sensor system can also generate the alert/alarm condition.
- Removing a ThinkTop with self-adjust activated, will immediately generate an alarm condition! If the ThinkTop has to be removed, not because of a valve maintenance issue, but for some other reasons, and you want to store the already adjusted data - disable the self-adjust function before removing the ThinkTop and enable it again once the ThinkTop is back on the actuator.
- After valve maintenance a disabling of the self-adjustment function is required before setting a new position, however, it is strongly recommended to make a complete new set-up (disable all functions in step 2 valve type - and make a complete new set-up).






*Unsafe practices and other important information are emphasized in this manual.
Warnings are emphasized by means of special signs. All warnings in the manual are summarized on this page.
Pay special attention to the instructions below so that severe personal injury or damage to the top unit are avoided.*

7.2 LED indication during normal operation







Yellow A Yellow steady: Position A (closed valve).



Yellow B Yellow steady: Position B (open valve).



Yellow C Yellow steady: Position C (Seat lift 1-2 or external sensors).



Green Green steady: Solenoid valves energized.



Note! During set-up LED lights have different functions.


8 Maintenance

*Study the instructions carefully.
Handle scrap correctly.
Always keep spare X-rings in stock.*

8.1 Dismantling of ThinkTop


Step 1

1. Untighten the two Allen screws and remove the ThinkTop from the actuator.
2. Pull out X-ring (19) and replace it.




Step 2

1. Untighten the four screws.
2. Pull off cover of ThinkTop.
3. Remove X-ring (9) (grey).




Step 3

1. Untighten screws.
2. Remove solenoid valves (up to three) and replace them with new ones.



Step 4

1. To dismantle the adapter (the lower part of the ThinkTop) from base (the middle part), unscrew the three screws.
2. Turn the lower part a little clockwise and pull.
3. Replace adapter if necessary.
4. Remove the black X-ring.




Note: Turn banjo connection!

*Study the instructions carefully.
Handle scrap correctly.
Always keep spare X-rings in stock.*

Step 5

To remove the sensor unit untighten screw and pull out the sensor unit.




8 Maintenance

Study the instructions carefully.
Handle scrap correctly.
Always keep spare X-rings in stock.

8.2 Assembly of ThinkTop

Step 1

Place sensor unit in base and tighten screw (torque: 1 Nm).




Step 2

1. Replace the black X-ring.
2. Assemble base with adapter by turning adapter slightly anticlockwise and tighten the four screws (1.9 Nm).


CAUTION!

Do NOT twist the X-ring in the groove!
The X-ring is not square; The highest (h) part must be placed as fig.




Step 3

1. Replace solenoid valves (up to three) with new ones.
2. Tighten screws (0.2 Nm).



Step 4


1. Replace the grey X-ring.
2. Replace cover of ThinkTop and tighten the four screws (0.6 Nm).



*Study the instructions carefully.
Handle scrap correctly.
Always keep spare X-rings in stock.*

Step 5

1. Replace the black X-ring.
2. Mount ThinkTop on actuator.



8 Maintenance


*Study the instructions carefully.
Handle scrap correctly.
Always keep spare X-rings in stock.*

8.3 Dismantling and assembly of Series 700 valves

Step 1


1. Remove the cover by loosening the four cover screws.
2. Separate the adapter from the base by loosening the three recess screws on top of the base.

Installation on air actuators:




Step 2

1. Fit air fittings on actuator.
2. Position packing retainer in recess on actuator top.
3. Fit counter nut and indicator (magnet) on actuator rod. Engage approx. 1/4" thread. Tighten counter nut and indicator with two wrenches.



Step 3


1. Place the two O-rings in the grooves in the bottom of the adapter. Then place the adapter on the actuator top. The small O-ring must be positioned over the air hole on the actuator.
2. Fasten the adapter with the four 5/16" Allen screws.



Step 4



1. Mount the base on the adapter in the position needed (can be rotated 120° in both directions). Note that one of the screw towers on the adapter has a guide recess (see * on drawing).
2. Remove x-rings (9) (grey) and (16) (black).
3. Replace with new ones.

CAUTION! Do NOT twist the X-ring in the groove! The X-ring is not square; The highest (h) part must be placed as fig.



The drawings show ThinkTop Devicenet 11-25 VDC.
 The items refer to the parts lists in the following sections


9.1 Drawings for ThinkTop DeviceNet 11-25 VDC



Note! This is the basic design.

The clearance should be approximately:


| | |
|-------------|---|
| W225 x H250 | (Unique SSV NC, SMP-SC/ - BV/ -TO, Unique Mixproof, MH, SBV) |
| W225 x H320 | (Unique SSV NO) |
| W225 x H300 | (LKLA-T) |



9 Part list and Service Kits

The drawings show ThinkTop Devicenet 11-25 VDC.
The items refer to the parts lists in the following sections

9.2 ThinkTop DeviceNet 11-25 VDC



9 Part list and Service Kits

The drawings show ThinkTop Devicenet 11-25 VDC.
 The items refer to the parts lists in the following sections

Parts list

| Pos. | Qty | Denomination |
|------|-----|--------------------------------|
| 1 | 1 | Shell |
| 3 | 1 | Screw |
| 4 | 1 | Washer |
| 5 | 1 | Sensor board |
| 6a | 1 | Solenoid valve (3/2) |
| 6b | 1 | Solenoid valve (3/2) or 5/2) |
| 7 | 1 | PT screw |
| 8 | 1 | Base |
| 9 | 1 | Special X-ring, grey |
| 10 | 1 | Air fittings |
| 11 | 1 | Blow-off valve |
| 12 | 1 | Thread plug, PG7, ø3 - ø6,5 mm |
| 13 | 11 | Cable gland, PG11 ø4 - ø10 mm |
| 14 | 1 | Gore Vent. mambrane |
| 15 | 1 | Adapter |
| 16 | 1 | Special X-ring, black |
| 17 | 1 | O-ring |
| 18 | 1 | Allen screw |
| 19 | 1 | Special X-ring |
| 20 | 1 | indication pin |



Service kits

| Denomination | Intern number |
|---------------------------------------|---------------|
| Sensor unit DeviceNet 11-25 VDC | 9612-5627-04 |
| Solenoid valve 3/2, 8 VDC | 9611-99-3748 |
| Solenoid valve 5/2, 8 VDC | 9611-99-3749 |
| Indication pin | 9612-5323-01 |
| Special indication pin, SRC-LS | 9612-6370-01 |
| Special indication pin, SSV-LS | 9613-1581-01 |
| Air fitting, ø6 mm | 9611-99-3405 |
| Air fitting, 1/4" | 9611-99-3433 |
| Gore vent | 9611-99-4722 |
| X-ring, pos. 9 | 9613-4564-01 |
| X-ring, pos. 16 | 9612-9994-01 |
| X-ring, pos. 19 | 9612-5696-01 |

9 Part list and Service Kits

The drawings show ThinkTop Series 700 Valves
The items refer to the parts lists in the following sections


9.3 Drawings for ThinkTop Series 700 Valves



Note! This is the basic design.

The clearance should be approximately:


| | |
|-------------|---|
| W225 x H250 | (Unique SSV NC, SMP-SC/ - BV/ -TO, Unique Mixproof, MH, SBV) |
| W225 x H320 | (Unique SSV NO) |
| W225 x H300 | (LKLA-T) |



9 Part list and Service Kits

The drawings show ThinkTop Series 700 Valves
The items refer to the parts lists in the following sections

9.4 ThinkTop Series 700 Valves



9 Part list and Service Kits

The drawings show ThinkTop Series 700 Valves
The items refer to the parts lists in the following sections

Parts list

| Pos. | Qty | Denomination |
|------|-----|-----------------------------|
| 1 | 1 | Shell |
| 3 | 1 | Screw |
| 4 | 1 | Washer |
| 5 | 1 | Sensor board |
| 6a | 1 | Solenoid valve (3/2) |
| 6b | 1 | Solenoid valve (3/2 or 5/2) |
| 7 | 1 | PT screw |
| 8 | 1 | Base |
| 9 | 1 | Special X-ring, grey |
| 10 | 1 | Air fittings |
| 11 | 1 | Blow-off valve |
| 12 | 1 | Thread plug, PG7 |
| 13 | 1 | Cable gland, PG11 4-10 mm |
| 14 | 1 | Pressure control valve |
| 15 | 1 | Adapter |
| 16 | 1 | Special X-ring, black |
| 17 | 1 | O-ring |
| 18 | 1 | Screw |
| 19 | 1 | Retainer |
| 20 | 1 | O-ring |
| 21 | 1 | O-ring |
| 22 | 1 | Indicator pin |
| 23 | 1 | Nut |

Service kits

| Denomination | 1/4" Air connec. |
|---------------------------------------|---------------------|
| Sensor unit DeviceNet 11-25 VDC | 9612-5627-04 |
| Solenoid valve 3/2, 8 VDC | 9611-99-3748 |
| Solenoid valve 5/2, 8 VDC | 9611-99-3749 |
| Indication pin | 9612-6357-02 |
| Air fitting, 1/4" | 9611-99-3433 |
| Gore vent | 9611-99-4722 |
| X-ring, pos. 9 | 9613-4564-01 |
| X-ring, pos. 16 | 9612-9994-01 |

How to contact Alfa Laval

Contact details for all countries are continually updated on our website.

Please visit www.alfalaval.com to access the information directly.

© Alfa Laval Corporate AB

This document and its contents is owned by Alfa Laval Corporate AB and protected by laws governing intellectual property and thereto related rights. It is the responsibility of the user of this document to comply with all applicable intellectual property laws. Without limiting any rights related to this document, no part of this document may be copied, reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the expressed permission of Alfa Laval Corporate AB. Alfa Laval Corporate AB will enforce its rights related to this document to the fullest extent of the law, including the seeking of criminal prosecution.