



General:

Default is: Step 2, tolerance is +/- 5mm
 Step 3-8, disabled

Timeout: A 60 sec. timeout is started as soon as any button(s) are released
 On timeout setup is exited with no changes saved

Flashing LED means no value set. Steady LED means value set as shown.

[D] LED: Active during set-up:

Flashing in step 1

Steady in all other steps

Or during operations, error condition:

Steady showing hardware fault, indication pin out of range

Flashing showing software fault

General commands in each step (except step 1):


- 0** Next step / skip step (In step 3-6 the program automatically moves to the next step when a position is stored)
- 5** Clear / disable step (In step 2 this resets the unit to default)
 (The command is accepted when all unlit LED's flash briefly)

It is recommended to reset the unit before performing a setup

Symbols:

- X** Push key on IR keypad with the same number.

Simple representation of LED indication:






Main Program loop

0 Enter Setup






Step 1



1 Save and Exit


2 Exit no change accepted

Step 2 – Setup valve type




5 Reset unit

Step 3 – Set closed position




Activate the valve to the closed position (De-energized)




5 Clear position

Step 4 – Set open position




Activate the valve to the open position (Energized)




5 Clear position

Step 5 – Set upper seat lift




Activate the valve to upper seat lift
When using an external sensor the sensor must be active when **1** is pushed




5 Clear position

Step 6 – Set lower seat lift







Activate the valve to lower seat lift
When using an external sensor the sensor must be active when **1** is pushed








5 Clear position

Step 7 – Set self adjust (Recommended: Disabled)



5 Disable function

Step 8 – Setup maintenance



5 Disable function